

Quick Guide for Honeywell/ADEMCO Vista Series

TURNING CHIME FEATURE ON/OFF (KEYPAD BEEP UPON ZONE OPEN):

- Enter [4-digit User Code], press 9

TESTING YOUR SECURITY SYSTEM:

- Enter [4-digit User Code], Press 5
- Press 1 the system will send a signal to the monitoring station. You should see a "CD" if successful. To reset the system, enter [4-digit User code] & 1

SETTING THE TIME/DATE:

- Enter [4-digit User Code], press #
- Press 6, 3
- Press * when Time/Date is displayed. Cursor will be over the hour setting. To move cursor forward, press * to go back, press #
- Enter 2-digit hour setting
- Enter 2-digit minute setting
- Press 0 for AM, or 1 for PM
- Enter 2-digit current year setting
- Enter 2-digit month setting
- Enter 2-digit day setting
- To exit, press * when cursor is at last digit or wait 30 seconds.

BYPASSING ZONE(S):

- Enter [4-digit User Code], press 6 enter [2-digit zone #]
- If you do not know the 2-digit zone # for zone you wish to bypass, check to see if a zone light, or your display has indicated an open zone. You may also call Client Services for assistance at 303-778-7000.!

ACTIVATING PREVIOUSLY BYPASSED ZONE(S):

- Enter [4-digit User Code], 1

TROUBLESHOOTING:

- To silence the keypad beeping: press ANY key on the keypad.
Please note, this will silence the trouble beeping temporarily & will begin again until the trouble has been resolved.
- To determine your type of trouble refer below: (words in "quotes" are fixed display keypad trouble codes)
 - Telco Fault or "Check 94": Indicates a telephone line fault or phone line disconnected
 - COMM FAILURE / "FC": the system has detected a communication problem. Call Client Services to test your system.
 - SYSTEM LO BAT / "BAT" w/o zone: the system backup battery needs replacement
 - LO BAT - Zone # / "BAT - zone #": a wireless device battery is low & needs replacement
 - MODEM COMM / "CC": a programmer in our office is remotely checking your system
 - POWER - indicator light is off: there has been a loss of AC power and the system is running on the backup battery
 - Busy-Standby / "dl": the system has been disabled; schedule service immediately.
 - OPEN CIRCUIT / "OC": the keypad has lost communication with the main panel, call Client Service to schedule a service appointment
 - Long Rng Trbl : the system has detected an issue with the cellular communication system. Please call Client Service to test your system communication.
 - Bell Failure / "Check 70": the system has detected a problem with your siren. Please call Client Services to schedule a service appointment.
 - Rcvr Jam / "Check 90": Please contact Client Service to schedule a service appointment.!
 - ALARM 1XX, FAULT 1XX, CHECK 1XX / "91": the system had detected a communication failure between the panel and a device zone. Please call Client Service to schedule a service appointment.