

Quick Guide for DSC PowerSeries

TURNING CHIME FEATURE ON/OFF KEYPAD BEEP UPON ZONE OPEN/CLOSE):

- Press & HOLD [Chime] key for 2 seconds, or press [*], [4].

SETTING THE TIME/DATE*:

- Press [*], [6], enter your [MASTER CODE], [1].
- Enter time in Hours, Minutes in 24 hour format... ie: [00:00-23:59].!
- Enter Date in 2-digit Month, 2-digit Day & 2-digit Year... ie: [MM DD YY].
- Press [#] to return to ready state

*please note, time/date may take up to 5 minutes to set in system after entry!

BYPASSING ZONE(S):

- Enter [*], [1], [2-digit zone # to be bypassed].
- Press [#] to return to ready state and you may arm the system normally.

ACTIVATING PREVIOUSLY BYPASSED ZONE(S):

- Press [*], [1], [0], [0].
- Press [#] to return to ready state.

TROUBLESHOOTING:

- To silence the keypad beeping:
- Press [#].

Please note, this will silence the trouble beeping temporarily & will begin again until the trouble has been resolved.

- To determine what is causing the trouble condition:

- Press [*], [2]
- Depending on your keypad type, you may scroll to read the trouble message(s) using the [< >] buttons, or a zone light will turn on. See below for a guide of trouble messages:
- 01 — Service Required - please contact Client Services immediately to schedule a service appointment
- 02 — AC Power Loss - the system has indicated a loss of power to the home, or has been unplugged and is running on backup battery power.
- 03 — Telephone Line Trouble - the system has detected a problem with the phone lines used to communicate to the monitoring system. Please call Client Services to test your system.
- 04 — Failure to Communicate - during an attempt to send a signal to our monitoring system, the system was unable to communicate. Please call Client Services to test your system.
- 05 — Zone Fault; Press [5] and corresponding zone will indicate. Please inspect zone, or schedule a service appointment to resolve.
- 06 — Zone Tamper; Press [6] and corresponding zone will indicate. Please inspect zone, or schedule a service appointment to resolve.
- 07 — Low Zone Battery; Press [7] to view wireless zone(s) with a low battery condition. You may need to press the [7] key up to 3 times to view the correct wireless zone causing the low battery trouble:
- 08 — Loss of Time on System Clock - please refer to setting Time/Date above to resolve